







# Cumulative Test: LabVIEW Basics

Test your “Basic” understanding of LabVIEW concepts by attempting the LabVIEW Basics Test. This test is recommended after you complete the seven modules found in the *LabVIEW Basics* section. The test includes 20 multiple choice questions.

1. Numeric controls are different from numeric indicators because they have a \_\_\_\_\_ background and \_\_\_\_\_.
  - a. White, Labels
  - b. Grey, Labels
  - c. White, Increment/Decrement Buttons
  - d. Grey, Increment/Decrement Buttons
2. To switch between the front panel and block diagram, select Window >> Show Block Diagram/Front Panel, or simply press \_\_\_\_\_.
  - a. Ctrl-E
  - b. Ctrl-Z
  - c. Ctrl-Shift-Y
  - d. Ctrl-B
3. The \_\_\_\_\_ function, which allows you to find functions and controls to which you do not know the navigation path, is located on the \_\_\_\_\_ palette.
  - a. , Functions
  - b. , Controls
  - c. , Functions and Controls
  - d. , Functions and Controls
  - e. , Functions
4. To copy an item on the front panel or block diagram, press <Ctrl-C> and then <Ctrl-V>, or simply hold \_\_\_\_\_ and click and drag and drop the item.
  - a. Shift
  - b. Alt
  - c. Ctrl-Shift
  - d. Ctrl

5. What is the correct order of execution of this code?



- a. Square Root, Add, Square Functions in Parallel
  - b. Add, Square Root, Square Functions in Parallel
  - c. Square Functions in Parallel, Add, Square Root
6. When placing a *new* function, control, indicator, or constant, the \_\_\_\_\_ feature wires the terminals together if placed within close enough proximity.
- a. Block Diagram Cleanup
  - b. Automatic Error Handling
  - c. Automatic Wiring
  - d. Retain Wire Values
7. The \_\_\_\_\_ chooses the best tool based on where the mouse pointer is placed in the LabVIEW environment.
- a. Wiring Tool
  - b. General Tool
  - c. Automatic Tool Selector
  - d. Operate Tool
8. The \_\_\_\_\_ is typically used during run time to change the value of a control.
- a. Operate Tool
  - b. Automatic Tool Selector
  - c. Select Tool
  - d. Shortcut Menu Tool
9. \_\_\_\_\_ any object in the LabVIEW environment provides quick access to most of the properties that can be changed.
- a. Left-Clicking
  - b. Right-Clicking
  - c. Selecting
  - d. Ctrl-Clicking
10. To find a quick description of an object in the LabVIEW environment, simply turn on \_\_\_\_\_ by pressing \_\_\_\_\_ and hovering over the object.
- a. Detailed Help, Ctrl-I
  - b. Context Help, Ctrl-U
  - c. Context Help, Ctrl-H
  - d. LabVIEW Help, Ctrl-Z

11. A \_\_\_\_\_ indicates that the VI is *broken* or not executable.
- a. Broken Run Arrow
  - b. Run Arrow
  - c. Wiring Diagram
  - d. VI Icon
12. If you are not getting the expected values from your VI, two good troubleshooting steps are \_\_\_\_\_ and \_\_\_\_\_, which show wire values during run time and slow down execution, respectively.
- a. List Errors, Highlight Execution
  - b. Probing Wires, Using Breakpoints
  - c. Probing Wires, Highlight Execution
  - d. Single stepping, Using Breakpoints
13. Being able to store a list of items in both a string and integer format allows for intuitive programming and a user friendly interface. This is made possible with the \_\_\_\_\_ data type.
- a. Enum
  - b. String
  - c. Integer
  - d. Cluster
14. The \_\_\_\_\_ data structure can be compared to a purse or wallet because a purse or wallet can hold many different things just as this data structure can hold multiple data types.
- a. Array
  - b. Cluster
  - c. Bundle
  - d. Container
15. For Loops have auto-index output tunnels, which automatically create \_\_\_\_\_ of data at the tunnel.
- a. Arrays
  - b. Containers
  - c. Graphs
  - d. Clusters
16. Being able to execute code based on a particular condition allows for logic to be built into a program. In LabVIEW, this is accomplished using a \_\_\_\_\_.
- a. While Loop
  - b. For Loop
  - c. Case Structure
  - d. Event Structure


17. A \_\_\_\_\_ allows a VI to run until a certain condition is met, such as pressing a Stop button on the front panel.
- a. While Loop
  - b. For Loop
  - c. Case Structure
  - d. Event Structure
18. A For Loop is different from a While Loop because it runs for a set number of iterations and does not require a \_\_\_\_\_. The number of iterations is set by the \_\_\_\_\_.
- a. Input Tunnel, Count Terminal
  - b. Conditional Terminal, Count Terminal
  - c. Conditional Terminal, Iteration Terminal
  - d. Input Tunnel, Count Terminal
19. To open a prebuilt VI to serve as a starting point or as a point of reference, open \_\_\_\_\_ and browse or search for the appropriate VI.
- a. LabVIEW Detailed Help
  - b. NI Example Finder
  - c. LabVIEW Context Help
  - d. KnowledgeBase Archive
20. Use \_\_\_\_\_ within the LabVIEW environment to see a quick description of any object on the block diagram or front panel.
- a. NI Example Finder
  - b. LabVIEW Manual
  - c. LabVIEW Context Help
  - d. LabVIEW Detailed Help

# Lab 01 - LabVIEW Short Course


## In-Class Problem Set

### 1. Division and Subtraction Calculator:



The following photo is when it is in 'Division Mode' since the On/Off button is off.  
The Led at the bottom right will light on if Y is divided by 0.



The following photo is when the switch button is turned on indicating that it is in Subtraction mode.




2. Convert from Feet to Meters and Miles:





## Lab 01 - LabVIEW Tutorials



# Take Home Problem Set

1. Create a VI which will calculate the Body Mass Index (BMI) of an individual.











2. Construct a VI that outputs a 2D array with 10 rows and 5 columns.

**Note:** To save results to excel: Click the Toggle Button, then click on “Confirm Save”.



A1										
	A	B	C	D	E	F	G	H	I	J
1	Untitled	Untitled 1	Untitled 2	Untitled 3	Untitled 4	Untitled 5	Untitled 6	Untitled 7	Untitled 8	Untitled 9
2	0.508347	1.280135	2.450813	3.970971	4.40522	5.772157	6.323435	7.154857	8.420489	9.181422
3	0.550905	1.522781	2.703817	3.126391	4.459319	5.368157	6.51434	7.136505	8.447067	9.486477
4	0.072841	1.943912	2.280844	3.776395	4.068627	5.765835	6.276709	7.017571	8.586288	9.997143
5	0.798299	1.500926	2.826214	3.936948	4.424557	5.226744	6.413994	7.841159	8.920646	9.647332
6	0.575478	1.878444	2.717635	3.631364	4.724415	5.650727	6.844652	7.714079	8.283814	9.804493

- Construct a VI with one numeric input  $n$  that builds an array containing  $n$  Fibonacci numbers, beginning with F1. Fibonacci numbers are the sequence of numbers, denoted by  $F_n$ .

**Fibonacci**

MAX Value

10

Array

n

0

0

n	$F_n$
1	1
2	1
3	2
4	3
5	5
6	8
7	13
8	21
9	34
10	55

stop

STOP

